

# POPPO ONE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

SAN ANTONIO APP CON  
 125.1 307.0  
 BAZ ATIS  
 119.325  
 KRND ATIS\*  
 290.525  
 KSKF ATIS  
 120.45 273.5  
 SAT D-ATIS  
 118.9  
 SSF ATIS  
 128.8

NOTE: Jet and turboprop aircraft only.

PRTZY

15.41°  
 17.6  
 9000  
 \*3700

MUGSY

9000  
 \*3700  
 15.4  
 12.71

11 NM

PPNUT  
FL220

DILLO  
FL220

15.11

9000  
 \*3700  
 17.2  
 14.1

10 NM

293°  
 113°

TRVLL

9000  
 \*3700  
 11.3  
 16.3

POPPO  
10000

See following page for arrival routes

DILLO TRANSITION (DILLO.POPPO1)

PPNUT TRANSITION (PPNUT.POPPO1)

PRTZY TRANSITION (PRTZY.POPPO1)

TRVLL TRANSITION (TRVLL.POPPO1)

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

# POPPO ONE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS