

TOP ALTITUDE:
(JETS) 5000
(PROPS) 3000

LOCALIZER
111.75 I-UZK 
Chan 54(Y)

I-OQV

HOOSIER
110.2 OOM 
Chan 39

LOCALIZER
111.15 I-OQV
Chan 48(Y)

LOCALIZER
111.15 I-FVJ
Chan 48(Y)

I-UZK

0.

2.3

3500
2300
2070
(2)

WEGEE

Diagram showing two overlapping rectangular regions, R-3401A and R-3401B, with diagonal hatching.

TAKEOFF MINIMUMS:

Rwys 5L/R, 14, 23L/R, 32: Standard.

POCKET CITY
113.3 PXV 
Chan 80

(NARRATIVE ON FOLLOWING PAGE)

NOTE: RADAR required.

NOTE: Select appropriate localizer/DME frequency/channel prior to departure.

NOTE: Turbojets accelerate to 250K until reaching 10000, if unable advise ATC.

NOTE: Assigned to aircraft with a requested altitude of 11 000 or above.

NOTE: Chart not to scale.