

AIRPORT DIAGRAM

AL-973 (FAA)

GAINESVILLE RGNL (GNY)
GAINESVILLE, FLORIDA

ATIS
127.15
GAINESVILLE TOWER *
119.55 353.7
GND CON
121.7

VAR 6.1° N
JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

294
A

HANGAR

29°42'N

GENERAL AVIATION TERMINAL

G.A. APRON

HANGARS

HANGARS

RUN-UP AREA

267.1°

0.5% UP

ELEV 130

FIELD
ELEV 151

067.1°

4158 X 100

ELEV 147

108.4°

7504 X 150

TERMINAL

TWR 202

FIRE STATION

29°41'N

RWY 07-25

PCN 43 F/B/X/T

S-107, D-172

RWY 11-29

PCN 56 F/B/W/T

S-120, D-218, 2D-372, 2D/2D2-870

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

82°17'W

82°16'W

AIRPORT DIAGRAM

GAINESVILLE, FLORIDA
GAINESVILLE RGNL (GNY)

SE-3, 08 AUG 2024 to 05 SEP 2024

SE-3, 08 AUG 2024 to 05 SEP 2024